-5 Measuring Alpha-Particle Emitters Flying in Nuclear Facility Buildings — A Highly Reliable Alpha Dust Monitor Using a GPS Scintillator Plate —



Fig.1-10 Developed (a) alpha dust monitor (b) and sample holder The alpha-particle detector was positioned in the sampling holder facing downward, and the detection end was placed in a light-tight box. A nozzle and an air sampler were also connected to the same light-tight box.





A dust monitor with a silicon surface barrier detector (SSBD) was introduced at a nuclear fuel facility to detect the airborne concentration of ²³⁸Pu and ²³⁹Pu released by past accidents. The SSBD energy resolution can distinguish ²³⁸Pu and ²³⁹Pu from naturally occurring radionuclides, such as radon (Rn) progenies (e.g., ²¹⁸Po with a 6.0 MeV alpha particle and ²¹⁴Po with a 7.7 MeV alpha particle). However, the SSBD frequently produces false alarms, especially in rooms with high humidity. Under false alarms, workers must evacuate, thus interrupting operations in the room. Thus, a more reliable dust monitor that has a high energy resolution but is more resilient against external noise is required.

Therefore, an alpha-particle spectrometer based on a ceriumdoped Gd₂Si₂O₇ (GPS) scintillator plate and a photomultiplier tube (PMT) was developed, as shown in Fig.1-10. The GPS scintillator plate is hexagonal and 50 mm in diameter with a scintillator layer of approximately 40 µm. The bottom face of the GPS scintillator plate was optically coupled to a PMT (R6233, Hamamatsu Photonics K.K., Hamamatsu, Japan) with a diameter of 3 mm in using an optical grease. The output signal from the PMT is amplified by a preamplifier (5625, Clear pulse CO., LTD., Tokyo, Japan) and transferred to a multi-channel analyzer (MCA; A2731, Clear pulse CO., LTD., Tokyo, Japan). The energy spectrum is then displayed in real-time. The alphaparticle detector was positioned facing downward and the detection end was placed in a black box, which was connected to a nozzle and an air sampler. When the air sampler operates, the



Fig.1-11 Simulation of the humidity condition Water was dropped directly onto the GPS plate.



Fig.1-13 Alpha energy spectra with and without dropping water

The ratio of the total counts with/without water was 0.84. The peak number of channels without and with water were 47.1 and 47.3 channels, respectively.

nozzle sucks up the air around the monitor, and any radioactive dust in the air is captured by the filter. The distance between the GPS scintillator plate and the filter was approximately 5 mm to allow for air passage. The ²⁴¹Am alpha source, Rn progeny collected on the air filter, and a PuO₂ particle were measured by our developed dust monitor. Water was dropped directly onto the surface of the GPS plate using a dropper to simulate high-humidity conditions (Fig.1-11).

The resulting energy resolution for 5.5-MeV alpha particles was $11.9\% \pm 0.2\%$ of the FWHM. A 92% efficiency was achieved, as was a uniform sensitivity. To eliminate Rn progeny counts, an energy window was set with the upper (ULD) and lower (LLD) channels of the Pu sample spectrum. By applying the energy window, the count-rate of the Rn progeny decreased by 77% (Fig.1-12). The resulting alpha spectra with and without dropping water are shown in Fig.1-13 for a measurement time of 5 min. The GPS scintillator plate could be used to measure the alpha spectrum even though the GPS scintillator got wet. The ratio of the total counts with/without water was 0.84. The peak number of channels without and with water were similar: 47.1 and 47.3 channels, respectively.

Overall, the developed dust monitor can be used to conduct alpha-particle spectroscopy despite the presence of water on the surface of the GPS scintillator plate. An alpha dust monitor using a GPS scintillator plate is therefore ideal for detecting alphaparticle emitters in places lacking temperature and humidity controls.

Reference

Morishita, Y. et al., Development of an Alpha Dust Monitor Using a GPS Scintillator Plate, Radiation Measurements, vol.122, 2019, p.115-120.